


Reach Desk Instructions Front Seat - Open Seat Bracket

To ensure that your Reach Desk is secure and will not tip while in use, follow the instructions below. **WARNING This desk is not intended to be used while the vehicle is in operation (Don't drive distracted!)**



- A** Place hook with short end cam buckle on left eye-bolt.
- B** Feed longer strap down and under the passenger seat base (between the seat bracket tracks and seat).
- C** Bring the longer strap with hook up from under seat and attach to the second eye-bolt.
- D** Tighten the strap by pressing down on the cam buckle release button and pull the longer strap until the desk is securely fastened to the seat.

Cam Strap fed underneath passenger seat and then secured to horizontal cross bar that supports the "glide track" the seat is attached to. *Note: be sure not to obstruct the glide track the seat rests on, so you can adjust the seat forward and back!*



Desk Placement




Photo of underneath passenger seat

How we recommend you secure our cam strap to the seat